



LED Direction Display
 Pin 1 X+ (front)
 Pin 2 X- (back)
 Pin 3 Y+ (left)
 Pin 4 Y- (right)
 Common cathodes

DESIGN: ambi02	NAME: ambisonic soundstage panner
FILE: ambisonic swinger02-02.sch	TITLE: current sources
CREATED: 03/10/01	MOD: 12/01/2007
SHEET: 2	OF 4
REV: 1.0	SIZE: A3