



THESE RELAYS DO THE ACCEPT LIGHTS
(AND LOGICAL STATE)

SOGND STANDS FOR "SELECT/OFFER GND"
YOU CAN BOTH SELECT SOURCE OR
OFFER WHEN YOU HAVE THE "ACCEPT" LAMP